



INSTALLATION, OPERATION AND MAINTENANCE MANUAL

FOR

UV Centurion

Germicidal Ultra Violet Lighting System



SYSTEM MODEL NO. _____

SYSTEM SERIAL NO. _____

SERVICED BY: _____

TEL. NO: _____

**CANADIAN
HEAD OFFICE
AND FACTORY**

CALGARY, ALBERTA
1401-HASTINGS CRES. S.E.
T2G-4C8

**USA
HEAD OFFICE
AND FACTORY**

DESOTO, KANSAS
32050 W. 83rd ST.
66018

**EASTERN
CANADA
FACTORY**

NEWMARKET, ONTARIO
1175-TWINNEY DRIVE
L3Y-5V7

SALES OFFICES ACROSS CANADA AND USA

RETAIN INSTRUCTIONS WITH SYSTEM AND MAINTAIN IN A LEGIBLE CONDITION
PLEASE GIVE MODEL NO. & SERIAL NO. WHEN CONTACTING
FACTORY FOR INFORMATION AND/OR PARTS

MAR 03

INSTALLATION, OPERATION AND MAINTENANCE MANUAL

TABLE OF CONTENTS

INTRODUCTION	3
WARRANTY	4
RECEIVING THE SYSTEM	4
INSTALLATION	5
CODES	5
ELECTRICAL INSTALLATION.....	5
OPERATION.....	5
MAINTENANCE.....	6
CLEANING PROCEDURE.....	6
LAMP REPLACEMENT	6
INSTALL THE NEW GROMMET AND LAMP IN THE REVERSE ORDER.	6
MAINTENANCE RECORD	7
TROUBLE SHOOTING	8

INTRODUCTION

All Engineered Air UV Centurion Germicidal Ultra Violet Lighting Systems are high quality products designed and manufactured to provide many years of trouble-free service. We recommend that this manual be read thoroughly to ensure efficient operation and proper maintenance of this equipment. The submittal record is considered to be part of the Installation, Operation and Maintenance Manual.

<p>Warning: Improper installation, adjustment, alteration, service or maintenance can cause property damage, injury or death. Read the installation, operating and maintenance instructions thoroughly before installing or servicing this equipment.</p>
--

Warning: Before installing or servicing this unit always turn off the power. There may be more than one (1) disconnect switch. Electrical shock can cause personal injury or death.

Caution: It is essential that adequate precautions be taken in any application of germicidal lamps. Prolonged exposures to high intensities of ultraviolet radiation can cause temporary, but painful inflammation of the conjunctiva (inflammation of the outer membrane of the eye), as well as histological effects in the cornea, iris, and lens of the eye. In extreme cases, permanent harmful effects can occur. Reddening or even burning of the skin (erythema), similar to sunburn, will be caused by excessive exposure to ultraviolet energy. The UV lamps should be turned off anytime there is any maintenance or service work being performed on the AHU, this includes the changing of filter(s). There is a UV light service switch that should be turned off before any work to the AHU is performed.

Caution: Never operate the lights outside the unit. Never enter the unit while the lights are operating. Germicidal UV light can cause skin burns or damage to the eyes. Unprotected skin within 2 feet of the light sources can burn within one (1) minute.

Caution: The system is provided with interlocking safety switch(s) to turn off the lamp(s) when the access is opened for service. This switch should not be bypassed under any circumstances.

Caution: The photolysis-emitting lamp can cause the production of ozone. Ozone can be a respiratory irritant in high concentrations. Maximum allowable level is 0.05 PPM for 24-hour continuous exposure. The system has been designed and selected to keep the ozone level considerably below these guidelines.

Warranty

ENGINEERED AIR will furnish without charge, F.O.B. factory, freight collect, replacement parts for, or repairs to products covered herein which prove defective in material or workmanship under normal and proper use within one year from the date of delivery, provided the customer gives *ENGINEERED AIR* written notice of such defects and provided that inspection by *ENGINEERED AIR* establishes the validity of the claim and all pertinent invoices have been paid in full.

The correction of such defects for replacement will be made only when the complete products or part claimed defective are returned to *ENGINEERED AIR*, transportation charges prepaid, if such return is requested by *ENGINEERED AIR*.

Repairs or replacements as provided by the foregoing paragraph shall constitute fulfillment of all *ENGINEERED AIR'S* obligations with respect to this warranty. *ENGINEERED AIR* shall not be liable to any damage to person or property, or loss of revenue, or expense incurred, irrespective of cause. This warranty does not apply to any products or parts thereof that have been subject to accident, misuse or unauthorized alterations, or where *ENGINEERED AIR'S* installation and service requirements have not been met. The foregoing warranty is in lieu of all other warranties, expressed or implied.

ENGINEERED AIR Warranty is void if:

1. The start-up and operation of the system is not in accordance with this manual.
2. The system is operated in a corrosive atmosphere.
3. The system is operated during building construction period.

SERVICE AND IN-WARRANTY PROCEDURE

Receiving the System

This Engineered Air UV Centurion System has been factory installed in the unit. On receipt of the lighting system, check electrical characteristics (see nameplate) to make sure the unit voltage is compatible with that available for the system. The system components were factory inspected and tested prior to shipping and were in good operating condition at that time.

INSTALLATION

Codes

In Canada:

The installation of this system must be made in accordance with The Canadian Electrical Code, Part 1 - C.S.A. Standard C22.1, Provincial and Local Codes.

In U.S.A.:

All power supply and control wiring to this system must be installed in accordance with the latest edition of the National Electrical Code (ANSI/NFPA 70).

Electrical Installation

Warning: Before installing or servicing this unit always turn off the power. There may be more than one (1) disconnect switch. Electrical shock can cause personal injury or death.

All wiring shall be installed in accordance with the requirements of the authorities having jurisdiction. **Do not cut holes in the bottom of the unit, as the floor of the unit should be waterproof.**

Wire lights as shown on the wiring diagrams.

Replacement wiring must be equivalent to the original wire.

OPERATION

Once you turn the UV Centurion system on, let it run continuously. The life of the lamps will be reduced if the unit is stopped and started more than once every 8 hours.

Note: 9000 hour estimated lamp life is based on the lamp being turned on and off no more than once every 8 hours.

Continuous operation of the UV Centurion system is important because the unit is designed to kill organisms on coils, filters, drain pans, other unit components and in the air. This process, to be effective, needs to be continuous because the organisms that are being eliminated grow continuously.

MAINTENANCE

Warning: If servicing any areas with live electrical power, turn off the power to avoid electrical shock, which could lead to injury or death.

A regular maintenance schedule must be established. Intervals will depend on the location of the UV Centurion system. The initial inspection and cleaning of the system should take place three months after installation. If there is excessive dirt on the lamp(s), a shorter inspection period should be used.

Cleaning Procedure

- Step 1: Turn off the UV lamps by turning the UV service switch to the OFF position. This will prevent any chance of electrical shock or exposure to the ultraviolet radiation! Allow the unit to cool for 5 minutes before continuing.
- Step 2: Visually inspect the lamps. If the lamps are covered with particulate wipe them with a dry cloth. If necessary, a standard window cleaner or alcohol can be used to assist in cleaning. *NOTE: Do not spray cleaner directly onto lamps, spray cleaner onto cloth, then wipe lamps.* Make sure the lamps are dry before restarting them.

Lamp Replacement

At the end of every 1 year period, or 9000 hours of operation, the lamps will need to be replaced. There is a hourmeter located in the control panel area of the AHU to keep track of the hours the lamps have been in operation. Log the hours and lamp changes on the Maintenance decal provided. Contact the factory for replacement lamps. If it is suspected that a lamp is not operating properly, see trouble shooting section.

To replace a lamp, turn off the UV lamps by turning the UV service switch to the OFF position. This will prevent any chance of electrical shock or exposure to the ultraviolet radiation! Allow the unit to cool for 5 minutes before continuing.

The lamps are supported at each end. One end is supported by a bracket and grommet, the other is supported by the lamp connection box and a grommet. Remove the cover to the lamp connection box located inside the unit at the end of the lamp(s). One lamp should be changed at a time to insure that correct size and type lamp replacement takes place. Unplug the connector from the end of the lamp. Holding the lamp at the ends, gently twist it while moving it toward the connection box. Once the end has cleared the lamp bracket, slightly move that end away from the bracket and slide the lamp the opposite direction to remove it from the connection box. A soapy water solution may assist in the lamps sliding in the grommets. Once the lamp has been removed, remove the grommet.

Install the new grommet and lamp in the reverse order.

TROUBLE SHOOTING

Warning: Trouble shooting should only be performed by qualified personnel.

Warning: Before servicing this unit, always turn off the power. There may be more than one (1) disconnect switch. Electrical shock can cause personal injury or death.

Caution: Do not proceed with the next step unless you are WEARING protective wear for your eyes and skin. Ultraviolet lamps can cause serious retina and skin damage - The face including ears should be covered using a face shield similar to a welders shield. Long sleeves, and gloves must also be worn)

A visual check of lamp operation is required from time to time to confirm lamp operation. Follow the Caution instructions above to protect yourself from the UV rays.

Once it has been determined a lamp or lamps are not operational, proceed as follows:

1. Confirm the correct power supply is connected to the UV lamp circuit.
2. Confirm the lamps are not intentionally cycled off by an *optional* ozone limiting switch. This switch is included with the dual frequency lamp option. Check the UV system wiring diagram to confirm if this feature is included.
3. Confirm all door switch interlock contacts are closed.
4. Confirm correct voltage is available at the lamp ballast's black and white power leads.
5. Once voltage is confirmed at the ballast and the lamp is still not operational, replace the lamp in question with a new lamp of the correct size and type. See instructions in the maintenance section (page 6) of this manual for instructions.
6. With a new lamp installed and the lamp is still not operational, replace the ballast connecting to that lamp. Make certain that all electrical connections have good electrical contact.

Replacement lamps and ballasts are available through you local Engineered air representative. The unit model and serial numbers are required to confirm lamp or ballast part numbers.